

### 3. INITIAL OPERATING PROCEDURE

#### 3.1 CHECKING THE PRINTED CIRCUIT BOARDS

First of all make sure that all boards are present and in their correct position. For the position and function of control elements, see page 9.

#### 3.2 MAINS SWITCH

When power is applied, the machine will automatically switch to the following mode:

- the red LED (13) lit to indicate "start" position, tonearm raised and the orange LED (11) lit to indicate "lift" position
- the green LED (35) lit to indicate 33 rpm speed selected.

If present, functions MUTE - MONO - REMOTE are deactivated (and relevant LEDs are OUT).

#### 3.3 TURNTABLE SPEED SELECTION

Speed can be directly selected by means of the three push- buttons marked 33, 45 and 78 provided motor is off (Stop position); it is also automatically switchable between 33 and 45 rpm by means of the center hub with large hole (27). In case this latter operating mode is chosen, press buttons 33 and 45 at the same time: when center hub is in the "up" position selected speed is 45 rpm and relevant LED is lit, while pushbutton 33 LED will flash; when center hub is in the "down" position, selected speed is 33 rpm and relevant LED is lit, while push button 45 LED will flash.

By pressing any of the three buttons 33, 45, 78, direct selection mode is restored.

Speed selection as per the above explained modes is remote controllable as well.