

**PROFESSIONAL TURNTABLE
SERIES TRS 9000
OPERATING MANUAL**

	page
1. PREPARATION	
1.1 Unpacking	1
1.2 Releasing the transport locks	1
1.3 Rack or console mounting	2
1.4 Mounting of pickup cartridge into shell	2
1.5 Tonearm balancing and adjusting of stylus tracking force	3
1.6 Antiskating device adjustment	5
1.7 Connections	6
2. NOMENCLATURE	9
3. INITIAL OPERATING PROCEDURE	10
4. OPERATING INSTRUCTIONS	
4.1 Controls location	14
4.2 Rotating speed selection	14
4.3 Stereo/Mono switching	14
4.4 Cueing to a desired point in the program	15
4.5 Reverse rotation	16
4.6 Starting directly at the turntable	16
4.7 Remote starting	16
5. TECHNICAL DESCRIPTION	
5.1 Drive system	17
5.2 Damping system	19
5.3 Pickup arm	19
5.4 Amplifiers	20
6. SERVICE	
6.1 Pickup arm	22
6.2 Lift	24
6.3 Braking	24
6.4 Power supply	26
6.5 Power motor control	27
6.6 Speed motor control	28
6.7 Logic control 1	29
6.8 Logic control 2	30
6.9 Out put amplifier	31
6.10 Preamplifier	32
6.11 Wiring diagram	33
6.12 Mother board	34
6.13 Keyboard	35
6.14 Peripheric PCB	36
7. TECHNICAL DATA	
7.1 Complete unit	37
7.2 Tone arm	37
7.3 Amplifiers	38
8. DIMENSIONS	
8.1 Rack version	39
8.2 Console version	40
9. PART LIST	
9.1 Suggested spare parts list	41