

Modulation line outputs are automatically muted until the turntable has reached the selected rotation speed.

This muting automatic function may be disabled by using the relevant switch located on Logic Control Board 2.

#### 4.5 REVERSE ROTATION

The reverse rotation of the turntable at normal operating speed exerts a definite strain on the cantilever of the pickup cartridge.

Nevertheless this operating mode presents no danger when special pickup cartridges designed for broadcast use are employed.

On the other hand, the reverse rotation is not suggested with pickup cartridges featuring an excessively large vertical tracking angle. With such cartridges as well as with high compliance ones, a tilting moment may arise which exceeds the structural force limits of the stylus assembly.

#### 4.6 STARTING DIRECTLY AT THE TURNTABLE

After the desired point in the modulation has been cued, the turntable may be started directly by a light pressing of the button "START" on the control panel.

#### 4.7 REMOTE STARTING

Turntable starting, like other functions, may be actuated from a studio control console as described at page 7, para 1.7.4.

However remote starting is possible only after pressing button REMOTE (38) and after illumination of the corresponding LED (37), or alternatively if a jumper is provided between pin 13 and pin 20 of the remote plug.