



- S18 - C24 connect with VAR SPEED BOARD
- S20 - C24 " " REMOTE
- S21 - C24 " " KEY-BOARD
- S22 - C25 " " LEFT BOARD
- S23 - C21 " " KEY BOARD
- S24 - C26 " " LINC OUT BOARD
- S25 - C25 " " EQUAL POT.
- S26 - C27 " " VOLUME POT.